


ПИЛА ДЛЯ РЕЗКИ МЯСА STARFOOD HL-2090



ПИЛА ДЛЯ РЕЗКИ МЯСА STARFOOD HL-2090

1	Door cover	61	Compression spring
2	Plastic sausage nozzle	62	Saw blade guard plate
3	Plastic sausage nozzle gasket	63	Square iron
4	Cross blade	64	Saw blade support bracket
5	Perforated plate D6	65	Saw blade bracket
6	Screwdriver shaft	66	Bearing positioning rod
7	Screwdriver	67	Saw blade support adjusting rod
8	Screwdriver bushing	68	Fixed base
9	Tee	69	Locking handle M8
10	Meat grinder locking handle	B1	Deep groove ball bearings 6203
11	Meat stuffer	B2	Flat washers 8
12	Meat grinder mounting base	B3	Standard spring washers 8
13	Shaft sleeve	B4	Hex head bolts M8*16
14	Shaft positioning sleeve	B5	Slotted flat-end set screw M6*8
15	Output shaft	B6	Deep groove ball bearing 6005
16	Bearing housing	B7	Shaft retaining ring 25
17	Drive shaft adjusting plate	B8	Flat key A6*70
18	Drive pulley	B9	Hex head bolt M8*20
19	Large pulley	B10	Hex nut M8
20	Motor pulley	B11	Hex nut M6
21	Motor (copper wire)	B12	Socket head cap screw M6*20
22	Motor baffle	B13	Belt
23	Motor housing left side panel	B14	Socket head cap screw M5*16
24	Foot pads	B15	Flat washer 12
25	Foot reinforcement plates	B16	Standard spring washers 12
26	Motor frame connecting crossbars	B17	Hex nuts M12
27	Motor frame	B18	Socket head cap set screws M6*16
28	Motor housing top panel reinforcement beam	B19	Flat key A6*30
29	Baffle swivel block	B20	Flat washers 6
30	Motor housing right side panel	B21	Hex head bolts M6*25
31	Switch box	B22	Round head square neck bolts M8*14
32	Motor housing top panel assembly	B23	Phillips head pan head self-tapping screws
33	Main frame welding	B24	Power cord (US plug)
34	Saw blade limit bracket welding	B25	Pull-out detachable screws
35	Saw blade limit adjustment plate	B26	Pushbutton switch
36	Pulley	B27	Phillips head pan head screw M4*16
37	Pulley shaft	B28	Flat washer 4
38	Guide seat bracket	B29	Hex nut M4
39	Workbench panel connecting plate	B30	Deep groove ball bearing 608
40	Workbench panel reinforcing plate-3	B31	Hex socket head cap screw M8*25
41	Workbench panel reinforcing plate-3	B32	Phillips head pan head screw
42	Workbench panel reinforcing plate-1	B33	Hex socket head cap screw M6*8
43	Panel	B34	Hex socket head cap screw M6*16
44	Adjustable horizontal backrest	B35	Hex socket head cap screw M6*30
45	Adjustable horizontal backrest lever	B36	Retaining rings for shafts 10
46	Adjustable worktable bracket	B37	Hex socket head cap screws
47	Locking handle M6	B38	Flat washers 10
48	Adjustable vertical backrest	B39	Hex nuts M10
49	Adjustable vertical backrest lever	B40	Hex nuts M5
50	Saw blade	B41	Flat washers 5
51	Driven wheel	B42	Hex socket head cap screws M6*35
52	Driven wheel spindle	B43	Retaining cylindrical pins D3*18
53	Adjustable upper wheel bracket	B44	Deep groove ball bearings 6202
54	Fixed upper wheel bracket	B45	Retaining rings for bores 35
55	Positioning pin	B46	Shaft retaining rings 15
56	Adjusting rod	B47	Hex socket head cap screws M4*8
57	Driven wheel cover base plate	B48	Deep groove ball bearings 6200
58	Driven wheel cover	B49	Phillips head pan screws M4*10
59	Column cover		
60	Transmission housing cover plate		