



NE PAS UTILISER LE DOUBLEUR DE TENSION AVEC LES MODELES 220 - 240V
DO NOT USE THE VOLTAGE DOUBLER ON 220 - 240 V MODELS

Index	Référence	Article	Tarifs
2	39641	LID ASSY RCOOK	417,90 €
3	39687	SCRAPER ARM HANDLE RCOOK	43,40 €
4	39688	ROBOT COOK LID	272,20 €
5	39638	LID SEAL ASSY RCOOK	89,20 €
6	39639	SCRAPER ARM ASSY RCOOK	103,50 €
7	39689	LID SCRAPER RCOOK	17,90 €
8	39690	LID SEAL (x2) RCOOK	45,00 €
10	39691	KNIFE ASSEMBLY ROBOT COOK	150,00 €
11	39858	BLADE CLEANING TOOL	23,50 €
12	39634	BOWL HANDLE ASSY RCOOK	87,40 €
13	39636	SAFETY ROD ASSY RCOOK	44,30 €
14	39633	SEAL ASSY RCOOK	32,70 €
15	500901S	УПЛОТНИТЕЛЬНОЕ КОЛЬЦО	12,80 €
16	39599	BOWL LOCKING WASHER RCOOK	46,80 €
17B	49120	MOTOR SUP. ASSY RCOOK RED	609,90 €
17A	39622	MOTOR SUPPORT ASSY GREY	609,90 €
18	501010S	УПЛОТНИТЕЛЬНЫЙ САЛЬНИК ДВИГАТЕЛЯ	19,40 €
19A	39074	BOLT COVER DARK GREY x4	7,90 €
19B	49122	RCOOK BOLT COVER RED x4	7,90 €
20	39642	CONTACT STUDS ASSY (x4)	61,40 €
21	39648	SAFETY BLOCK ASSY RCOOK	81,10 €
22	104122S	ВЕНТИЛЯЦИОННАЯ РЕШЕТКА	17,40 €
23	39855	GENERAL SWITCH RCOOK	16,50 €
24	39692	CONTROL BOARD RCOOK	495,60 €
25	39621	KEYS ASSY RCOOK	14,20 €
26	39686	CENTRAL LOCKING ASSEMBLY	29,00 €
27	39620	PROGRAMMING KNOBS ASSY	23,50 €
28	39853	DISPLAY WINDOW RCOOK	20,10 €
29	39619	FRONT PLATE RCOOK	23,10 €
30	39617	CONTROL PANEL SUPP. RCOOK	24,70 €
31	39618	ROTATING KNOB SET RCOOK	54,30 €
32	39859	CONTROL PANEL ASSY RCOOK	25,40 €
33	39631	MOTOR ASSY RCOOK	1 044,30 €
35	110013S	SHAFT DEFLECTOR R402/1	10,20 €
36	39694	MOTOR DEFLECTOR RCOOK	22,00 €

Index	Référence	Article	Tarifs
37	106268S	КОМПЛЕКТ ВЕРХНИХ УПЛОТНИТЕЛЕЙ С ФЛАНЦАМИ	112,20 €
38	501270S	LOWER MOTOR BEARING	36,40 €
39	39695	MOTOR FAN	12,50 €
40	102920S	КАРТА ОПРЕДЕЛЕНИЯ СКОРОСТИ	38,50 €
41	39696	VENTILATION BAFFLE RCOOK	30,40 €
42	39697	AUXILIARY FAN RCOOK	49,00 €
43	39879	ДЕМПФЕР В СБОРЕ	18,60 €
44	129451S	SAFETY SWITCH 87-53 1A66 CUTTER	30,50 €
45	39623	VARIATOR SUP.ASSY RCOOK	34,70 €
46	39630	VARIATOR ASSY RCOOK	1 250,50 €
47	39698	VARIATOR/PTO ADAPTER	20,10 €
48A	39614	BASE ASSY DARK GREY RCOOK	122,30 €
48B	49121	RCOOK BASE ASSY RED	126,30 €
49	39928	НОЖКА (x4)	11,30 €
50	49691	ROBOT COOK SMOOTH BLADE	150,00 €
A	39699	POWER CORD EUR	42,10 €
B	39637	BOWL ASSY 230V RCOOK	890,10 €
C	39854	ROBOT COOK ACCESSORY ADD	1 077,00 €